



## REMOTE HANDSET CODING INSTRUCTIONS ATA: EAT - MANUAL RELEASE CORD BUTTON

### TO CODE YOUR NEW EAT BUTTON USING THE MOTOR PANEL

If you have access to the motor operating your door/gate, you can use these instructions. However, if the door/gate motor is shared with other tenants at a residential/commercial complex, **do not** use these instructions.



1. Ensure your new battery is installed correctly in the new EAT
2. Remove the Plastic shield (IF one is in place) covering your motor panel button
3. Press and hold down the DOOR CODE button on the motor panel (keep it held down) whilst you:
4. Press the EAT button for TWO SECONDS, release for TWO SECONDS, then press it again for TWO SECONDS (see Figure 1)
5. Release the DOOR CODE button on the motor panel
6. Press the EAT button to test operation of the door



### TO REPLACE THE BATTERY IN YOUR EAT:

1. Rotate the cover Clockwise to OPEN the bottom of the EAT (see Figure 2)
2. Use a non metallic object (such as a pen) to flick the button shaped battery out of the circuit board (see Figure 3)
3. Place the new battery into the battery holder, then firmly press down until it is fully positioned (see Figure 4)
4. Sit circuit board into bottom of the EAT case (it should sit into the grooved section)
5. Rotate the cover Anti-clockwise to CLOSE the bottom of the EAT

Figure 1:




Figure 2:




Figure 3:





Figure 4:



Thank you for your purchase.

Our Customer Support team are available 8am-5pm on (07) 5476 9227 if you have any further questions.