



REMOTE HANDSET CODING INSTRUCTIONS DOMINATOR 315MHZ



TO CODE YOUR NEW REMOTE USING THE MOTOR PANEL

If you have access to the motor operating your door, you can use these instructions. However, if the door/gate motor is shared with other tenants at a residential/commercial complex, **do not** use these instructions.

To code in the remote to operate the garage DOOR:

1. Remove the cover on the door's motor CONTROL PANEL
2. Set the 9 switches to the combination shown in DIAGRAM 1 overleaf

If you have an old DOMINATOR remote with pinned DIP SWITCH codes you need to change the combination to the below so it will still work alongside your new remote:

1. Open the battery cover on your old remote to view the pinned switches
2. Set the 9 switches to the combination shown in DIAGRAM 1 overleaf

Thank you for your purchase.

Our Customer Support team are available weekdays 8am-5pm on (07) 5476 9227 if you have any further questions.

DIAGRAM 1 : CONTROL PANEL:

1	2	3	4	5	6	7	8	9



DIAGRAM 2 : DIP SWITCH PATTERN TO OPERATE AN OLD DOMINATOR REMOTE:

1	2	3	4	5	6	7	8	9



OPEN COVER ON BACK OF THIS OLD REMOTE, TO ACCESS THE DIP SWITCHES.

Thank you for your purchase.

Our Customer Support team are available weekdays 8am-5pm on (07) 5476 9227 if you have any further questions.